

PR9200 Application Note:

PR9200 Serial Interface



Revision History

Version	Date	Description
01	2014-03-18	Initial release
02	2016-05-18	Modified pin information of UART, SPI and I ² C Added SPI timing information
03	2016-09-02	Added I2C slave address information
04	2018-04-20	Modified mode change of SPI
05	2020-11-01	Modified SPI Interface

Document Summary

- PR9200 can support three digital interface to HOST: UART, SPI, I2C.
- Default interface is UART.
- As modifying firmware a little bit, user can easily change interface method to SPI or I2C.

UART Interface (1/2)

- Pin Information

- P00: UART0 RXD
- P01: UART0 TXD
- P10 or P16: IRQ*
 - P10: for PRM92x20 and PRM92x30
 - P16: for RED4 and RED5

*Output, this pin is controlled by PR9200

- PR9200 firmware for UART

- For change serial interface or baudrate, reprogram new firmware after modify and compile the firmware

- How to modify firmware

- File: config.h

```
051 // RCP Path
052 //#define FEATURE_GPIO_SIO_SEL
053 #define FEATURE_UART_RCP
054 //#define FEATURE_SPI_SLAVE_RCP
055 //#define FEATURE_I2C_SLAVE_RCP
```

Remove comment!

- How to change baudrate


- File: config.h

```
073 //////////////////////////////////////
074 // UART Feature
075 //////////////////////////////////////
076 #define UART0_BAUDRATE (115200)
```

Modify baudrate!

UART Interface (2/2)

- Message Exchange (ex. Tag Read)



- IRQ Pin ([Optional](#))
 - Slave changes IRQ to low when there is packet that slave response to master after command processing

SPI Interface (1/3)

- Pin Information

- P04: SPI TXDS
- P05: SPI RXDS
- P06: SPI CLK
- P07: SPI SEL
- P10 or P16: IRQ*
 - P10: for PRM92x20 and PRM92x30
 - P16: for RED4 and RED5

*Output, this pin is controlled by PR9200

- PR9200 firmware for SPI


- For change serial interface, reprogram new firmware after modify and compile the firmware
- How to modify firmware
 - File: config.h

```
051 // RCP Path
052 // #define __FEATURE_GPIO_SIO_SEL__
053 // #define __FEATURE_UART_RCP__
054 #define __FEATURE_SPI_SLAVE_RCP__
055 // #define __FEATURE_I2C_SLAVE_RCP__
---
```

Remove comment!

SPI Interface (2/3)

- SPI timing information




Time	Min.	Max.
t_1	SCK 2 cycle	SCK 3 cycle
t_2	0	
t_3	SCK 1 cycle	

When SCK is 250kHz

Time	Min.	Max.
t_1	8 us	12 us
t_2	0	
t_3	4 us	

SPI Interface (1/3)

- Message Exchange (ex. Tag Read)



- Mode change message (**mandatory**)
 - Length: 2bytes
 - Use for Read/Write mode change
 - Master: Write → Read
 - Slave : Read → Write
 - For read response: 0xBB 0x0A (No CRC)
- IRQ Pin (**Optional**)
 - Slave changes IRQ to low when there is packet that slave response to master after command processing.

*For the detail information, refer to ACP document

I2C Interface (1/2)


- Pin Information
 - P11: I2C SDA
 - P12: I2C SCL
 - P10 or P16: IRQ*
 - P10: for PRM92x20 and PRM92x30
 - P16: for RED4 and RED5
- I2C Slave Address : 0x49
- PR9200 firmware for I2C
 - For change serial interface, reprogram new firmware after modify and compile the firmware
 - How to modify firmware
 - File: config.h

```
051 // RCP Path
052 // #define __FEATURE_GPIO_SIO_SEL__
053 // #define __FEATURE_UART_RCP__
054 // #define __FEATURE_SPI_SLAVE_RCP__
055 #define __FEATURE_I2C_SLAVE_RCP__
```

Remove comment!

I2C Interface (2/2)

- Message Exchange (ex. Tag Read)



- Mode change
 - SLV(Slave address) + R/W (R: Read, W: Write)
 - Slave address : 0x49
- IRQ Pin (Optional)
 - Slave changes IRQ to low when there is packet that slave response to master after command processing.

*For the detail information, refer to ACP document

Address information

PHYCHIPS Inc.

#104, 187 Techno 2-ro, Yuseong-gu, Daejeon, Korea (Yongsan-dong, Migun Technoworld 2), 305-500

Web site : <http://www.phychips.com>

E-mail : sales@phychips.com

TEL : +82-42-864-2402

FAX : +82-42-864-2403

Disclaimer: PHYCHIPS reserves the right to make changes to the information in this document without prior notice. The purchase of PHYCHIPS products does not convey any license under patent rights owned by PHYCHIPS or others. PHYCHIPS does not assume any responsibility for the use of this product. It is the customer's responsibility to make sure that the system complies with regulations.

© 2020 PHYCHIPS Inc. All rights reserved. The reproduction of this document is NOT allowed without approval of PHYCHIPS Inc.